

CTSVW002.2

Volkswagen Steering Wheel Control Interface





















Vehicle Application

VW Passat (B6, 3C, B7, 3C36)	2005 - 2015	VW Amarok (2H)	2010>
VW Golf (Mk5/Mk6)	2005 - 2015	VW Suran	2009>
VW Touran	2003 - 2015	VW Vento	2005 - 2011
VW Transporter	2003 - 2015	VW Sagitar	2005 - 2011
VW Polo (9N, 9N3, 6R)	2005 - 2014	VW Magotan	2005 - 2011
VW Jetta	2005 - 2015	VW Fusca	2005 - 2011
VW EOS (1F)	2006 - 2015		
VW Tiguan (5N)	2007 - 2015	VW Touareg	2010>
VW Scirocco	2008 - 2015	VW UP!	2011 - 2016

Key Features

- Retains Steering Wheel Controls
- Retains Factory Phone Buttons
- Provides Speed Pulse, Park Brake, Reverse Gear Outputs





ABOUT THIS PRODUCT

CTSVW002.2

CAN-Bus Steering Wheel Control Interface for Volkswagen vehicles with RCD200/300/310/500/510 original stereo and Quadlock connector

WIRING COLOUR CODES

Yellow Permanent 12V **Purple** Right Rear Speaker + Purple/Black Right Rear Speaker -Black Ground Green Left Rear Speaker + Red Ianition 12V Green/Black Left Rear Speaker -Orange Illumination Grev Right Front Speaker + Pink Speed Pulse Grey/Black Park Brake Right Front Speaker -Green White Left Front Speaker + Purple/White Reverse Gear White/Black Left Front Speaker -

PRIOR TO INSTALLATION

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure that the correct tools are using during the installation to avoid damage to the vehicle or product. **Connects2 can not be held responsible for the installation of this product.**

TECHNICAL SUPPORT

Connects2 Ltd. want to provide a fast and suitable resolution to any problems encountered during installation of this product. To get in touch with our dedicated technical support team, please fill in a ticket at **support.connects2.com** and provide as much information as possible.

FOLLOW US ON SOCIAL MEDIA for all the latest updates



/CONNECTS2
Watch us on YouTube



Like us on facebook



CONNECTS2LTD Follow us on instagram







FITTING GUIDE

- 1. Remove and disconnect the original head unit.
- 2. Connect the 12 way molex connector of the head unit patch lead (supplied separately) to the interface.





3. Connect the opposite end of head unit patch lead to the head unit steering wheel control input on the back of the aftermarket head unit.

NB: This may be a 3.5mm jack plug or a wire input depending upon the head unit brand being fitted. Please see the head unit installation manual for further information on where to connect.

Important: This step must be completed before connecting power to the interface. Failure to so do may result in no steering wheel control function.



4. Connect the 14 way molex connector to the interface





5. Connect the male power/speaker ISO harness to the female power/speaker ISO harness from the aftermarket head unit. For aftermarket head units without an ISO connector, please refer to "Wiring Colour Codes" on Pa. 2.





FITTING GUIDE

6. Connect the female vehicle specific connectors on the harness to the male vehicle connector from the vehicle. Test head unit for correct operation.

STEERING WHEEL CONTROL FUNCTIONALITY

Config 1.

Original Button	Function
Volume +	Volume +
Volume -	Volume -
Right Arrow	Track +
Left Arrow	Track -

Phone Button Pick Up (Short Press)
Phone Button Pick Up (Short Press)
Hang Up (Long Press)

Mute Mute



Config 2.

Original Button	Function
Volume +	Volume -
Volume -	Volume -
Up Arrow	Track +
Down Arrow	Track -
OK	Source
Star	Mute
Menu	Menu

